
## **OPERATING AND** INSTRUCTION MANUAL

### Upright Commercial Display Cooler









Inox-Bázis Kft. Arany János u. Központi Major 9090 Pannonhalma, Hungary info@inoxbazis.hu







Before installing your cooler, read these instructions carefully.

# SAFETY PRECAUTIONS

 The purpose of the safety precautions in this manual is to ensue safe and correct use of the unit to minimize risks that could cause serious damage and injury to you or other persons. The safety precautions are divided into WARNINGS and CAUTIONS. Cases where improper handing of the unit could lead to death or serious injury are listed under the "AWARNING" heading. However, the cases listed under the "ACAUTION" heading could also lead to serious results. To ensure the safety, adhere strictly to both types of safety precautions

- Text set off by the exclamation mark contains information that should be strictly adhered to
- After reading the instruction manual, store it an easily accessible place where the user(s) of this product can easily find it.

#### PRECAUTIONS FOR INSTALLATION





Installation should be performed only by the dealer or a qualified expert. Attempting to install the unit yourself could result in water leakage, refrigerant leakage, electrical shock, or fire.

#### PRECAUTIONS FOR INSTALLATION

### **AWARNING**



Installation should be performed only by the dealer or a qualified expert. Attempting to install the unit yourself could result in water leakage, refrigerant leakage, electrical shock, or fire.





Never splash water directly onto the product or wash with water as short circuit and electrical leakage could result.






Never put flammable or volatile substances into the unit as explosion and fire could result.





Do not damage, modify, excessively bend, strain, twist or bundle up the power cord. Also, placing heavy objects the power cord or squeezing it in a tight place could damage it, possible resulting in electrical shock or fire.







Never use flammable spray cans or leave flammable substances near the unit. Sparks from electrical switches could result in explosion and fire





# SAFETY PRECUATIONS

#### **AWARNING**



The cooler is intended for storage and display of beer and beverage for sale. Do not use for other purpose than the intended as this could adversely affect items placed in the unit.





Never attempt to insert fingers, sticks, etc.fan is rotating at high speed inside the outlet.Injury, electrical shock and improper operation could result





For indoor use only. Using the unit in a location exposed to rain could result in electrical leakage and electrical shock.



Install the unit in a location where the floor

is sturdy enough to support the load of the

unit. If the floor is not sturdy enough or

products could cause personal injury.

installation is incorrectly performed, the

unit could tip over and falling shelves and



Never place heavy objects or items containing water op top of the unit. Objects could fall down and cause injury and spilled water could deteriorate the insulation of electrical components and result in electrical leakage.



If you find gas leakage, please don't touch the cooler and close gas and open the door for ventilation. Gas leakage cause explosion, fire and fire injury.






Store the unit in a location where it is not exposed to rain. Using a unit that has been exposed to rain could result in electrical leakage and electrical shock.



Away from hot air sources. Cooling performance is reduced if the unit is placed near heat sources such as hot plates and stoves and if it is exposed to direct sunlight.









Should the unit need temporary storage, make sure not to store the unit in a location where children play and take precautions so that the door cannot be completely closed. This will minimize the risk that a child becomes trapped inside the compartment.

#### **△WARNING**

#### WELL VENTILATED PLACE

Please make more than 10cm space between cooler and wall. If there are no space, cooling capacity can drop down.




If installation in a damp location is unavoidable, also install an electrical leakage circuit breaker. If no electrical leakage circuit breaker is installed, electrical shock could result.






Never hang from the door or climb onto the unit. The unit could tip over or fall and cause material damage or injury.












Grasp the handle when closing the door. Holding at other positions could result in pinched fingers and injury.









Make sure that the unit does not tip over or fall when it is moved. A falling unit could cause serious injury.









When disconnecting the power cord plug

from the wall outlet, hold at the plug main

body close to the outlet. Pulling the cord

Do not throw items onto the shelves and do not place items totaling more than 30kg on each shelf. The shelf could fall down, possibly cause injury.





Be sure attach and secure shelves correctly. An improperly attached shelf could fall down and cause injury.



### PLACING ITEMS IN THE SHOWCSE

This showcase employs a forced circulation of cold air system. If circulation of cold air is obstructed, the items will not be adequately refrigerated. Pay attention to the following points:

- Do not let items obstruct the cold air inlet and suction outlet.
- Place items so that they do not protrude from the shelves. The gap between the shelves and the door is used for circulation of cold air.
- Place items evenly on all shelves.
- Please do not display goods on the bottom. Please put goods on the shelf

# **CLEANING**

#### **△** WARNING

To prevent any electrical shock hazards or injury by rotating circulation fan, always disconnect the power cord plug from the wall outlet before cleaning.


#### EXTERIOR AND COOLER COMPARTMENT

• Wipe with a soft, dry cloth. If very soiled, wipe with a cloth that has been moistened with a detergent. Then wipe with a cloth that has been dipped in water

#### **AWARNING**

WARNING: Do not splash water directly onto the cooler and do not wash with water. Short-circuit and electrical shock could result

- Clean the cooler regularly to keep it clean at times.
- Never use polishing powder, soap powder, benzene, Oil or hot water as these will damage the painting and Plastic components



To ensure the safety, perform the following checks after cleaning

- Is the power cord plug firmly inserted into a dedicated wall outlet? Confirm that the plug is not abnormally
- Check the power cord for cracks and damage. Should the slightest irregularity be observed, contact the dealer from whom you purchased this unit or our customer's service.

# **HOW TO USE**

#### **BEFORE USE**

- Remove shipping package, tape, etc and leave doors open ventilation for a while.
- The unit is cleaned before shipment. However, clean the compartment interior once after delivery
- Please insert power supply plug into the wall outlet, single-phale to cat voltage. • Allow the unit to operate for about 1 hour to cool the compartment before placing items in the cooler

#### WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

• Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the circuit-breaker, the compressor may be overloaded, and/or other damage may occur

#### TEMPERATURE ADJUSTMENT

• For showcase cooler, the interior temp. during fully loaded at factory default setting of position at 4-5 will be kept at 0-10°C. If the ambinet temp, is extremely high or the stuffing food inside is too much that might cause the interior temp. a little bit higher. So, it would be better turn the thermostat right so as to maintence the right temp. On the opposite, if the ambinet temp. is very low or empty loaded, or in less food storage, the interior temp. might be able to reach minus  $0^{\circ}$ C, and in return to cause the evaporator ice up;Thus,it would better switch the thermostat back to left so as to relieve something.

- Defrosting is performed automatically and drain water is collected in the drain tray.
- Water is in the drain tray is evaporated automatically. In humidity, large amount of water in the drain tray, so please throw away drain water once a day.

#### EFFICIENT USE

Please follow the below instruction, you could save energy.

- To prevent cold air from escaping, open and close the door quickly and keep the door opened for as short a time as possible
- Please install the unit in the place which is well-ventilated.

#### SHELF HEGITH ADJUSTMENT

In case the unit shows operating problems

The shelf height can be adjusted

• Arrange the shelves in accordance with the dimensions of the items to be placed in the cooler

check the following prior to calling the authorized service company:		
SYMPTOMS	POSSIBLE CAUSE	SOLUTION
The unit is not operating	Faulty electrical contact	Verify electrical connections
	Poor electrical power	Check the power connection and electrical outlet
	Thermostat setting "0"	Change the thermostat setting to a higher number
Not reaching desired temperature	Unit is exposed to direct sun light	Relocate the unit to a shaded area
	Thermostat is not propertly adjusted	Adjust the thermostat setting to a higher number
	Clogger condenser	Review Maintenance instrutions listed in the manual
	Blocked grills	Clean the grills of any debris collected
	Door not properly closed	Check the leveling of the unit and door seal
	Products poorly distributed or excess product load	Redistribute the product load according Start instrutions
	For Models with electronic temperature controller, indicates E0 or E1	Unplug the unit from the outlet.If the error continues, contact an authorized service technician
Abnormal noises	The unit is not properly level	Level the unit following the Installation instructions
	Friction with other objects	Move the unit and avoid contact with other objects
Water on the floor	Drain hose is outside of the drain pan	Lovate the hose in the drain pan

#### WARRANTY & SERVICE

- Warranty is valid for one year from the date of purchase.
- The warranty covers defective parts and workmanship. The following items are not covered under warranty:
  - 1.Loss of products. 2. Damages caused by transportation.
  - 3. Damages caused by modifications made by
  - unauthorized individuals. 4. Fluorescent lights, glass parts or plastic component
  - 5. Worn out plugs or defective electrical components.
  - 6. Maintenance of the unit.
- Warranty is valid showing the purchase receipt.
- We offer a professional service network which offers the necessary technical support for your unit.
- See contact information in the back of the Manual.